

## INSTRUCTION

Before use read the details carefully and retain the instruction manual!



Articles for baby and child

## Rodeo

- 3-wheeled sport stroller with reversible seat unit
- swivable and lockable front wheel
- height adjustable handlebar
- suitable from 6 months to 3 years (max. 15 kg) with carry cot from date of birth (max. 15kg )
- 3-times adjustable seat unit
- weight: 10,5 kg
- corresponding to the EN norm EN 1888 : 2005

**This product is not usable for running or skating!**

**Dear Customer,**

***Congratulations on the purchase of your ABC-Design Stroller. We are pleased that you have chosen one of our products and hope that you will be completely satisfied with the service you receive from the product. We advise you to read the Instruction Leaflet carefully before use of the pram and then to keep it in a safe place. If you fail to do this the safety of your child can be jeopardised. Kindly pay attention to the washing and care instructions so that you enjoy long and trouble free use of your new purchase.***

***Your ABC-Design Team***

### **Hints for care and use**

1. The manufacture of materials used in the fabrication of this product meet the standards required by the AZO, EN71-2 und EN71-3. for clothing claimed light originality values. However, we advise you not to expose the product to the sun for a long time. Attrition and fading of colours during heavy solar radiation do not justify a damage claim. The fabric case of your stroller is washable. You can wash the case by hand or machine cold wash.
2. Each product frame is manufactured according to EN 1888: 2005 standards. To maintain the safety of your product, the moving components must be lubricated regularly and if required rivetted.  
Look out: Use only silicon-oil or silicon-spray for oiling.
3. Regular care and maintenance contribute to the safety and longevity of your product. Environmental influences such as salty air, road strewn salt or acid rain as well as outdoor storage contribute towards corrosion. Therefore always store your pram indoors.
4. We recommend regular maintenance of all varnished components. Should the frame and varnished components become soiled use a damp cloth moistend with water diluted mild detergent to wipe away the dirt.
5. Damaged air tubes are no reason for reclamation. Spare tubes can be bought in all retail shops.

By adhering to the aforementioned hints you will enjoy satisfactory use of your ABC-Design product for a long time.

## 1. Unfolding the stroller

Pull the handle of the sport stroller upwards until the frame locks.

**WARNING:** Please make sure that all locks are closed before using.



## 2. Wheel Installation

Fix the rear wheels on the axle until it locks.

For removing the rear wheels, as shown on the photo, pull the lever downwards and take away the wheel.



For front wheel installation, please insert the front wheels as shown on the picture. Put the front wheel into the shaft until it locks.

For removing the front wheels, turn the plastic button in the direction as shown on the picture. Remove the wheel.



### 3. Swivelling/Locking system for the front wheels

For fixing the front wheel push down the lever as shown on the picture.

For a swivelling front wheel push the lever upwards.



### 4. Fixing and removing of the break

For fixing the breaks you have to push down the lever.

For removing the breaks you have to lift the lever.



## 5. Fixation seat unit

Please fix the seat unit onto the frame as shown on the pictures.

Please make sure that the seat unit is correctly locked onto the frame.

For reversing the seat unit push up both security buttons as shown on the picture.

Now move the seat unit slightly and take it away.



## 6. Fixing and removing of the bumper


For fixing the bumperbar please take it into both plastic fixations on the left and right side as shown on the stroller.

For removing the bumper from the stroller turn both clips to the inner side and pull the bumper to the front.



### 7. Belt locking


For locking the belt put both plastic parts (1) together until it locks.



### 8. Belt opening

For belt opening, put both plastic parts together (1) and then pull it apart (2).

**WARNING:** Please use the pelvic belt together with the crotch belt



### 9. Seat unit adjustment

For adjusting the seat unit, pull the lever on the rear side to the top and adjust it.

When you have reached the requested position let off the lever and it locks automatically in the position you want.



### 10. Adjustment of the handlebar

To adjust the handle in height you have to push the button at the top as shown on the photo. Now you can fix the handlebar in the requested position.



### 11. Adjustment of the legrest


For adjusting the legrest push both buttons on the left and right side of the legrest and fix it in the requested position.



## 12. Folding of the stroller

For folding the stroller please turn the black button to the left (1) and push the black button at the handle (2) at the same time push the handle down.

Now you can easily fold the stroller.



**Remark:** For building up the stroller use the same procedure as mentioned under point 1.

**WARNING:** Please make sure that all locks are closed before using.

## Tips

in case of reclamation

- Please read this instruction carefully before using the stroller. If you don't pay attention to these instructions, the safety of your baby can be in danger.
- This stroller is suitable for babies from the age of 6 month (by using a carry cot from date of birth) till the age of 3 years and a weight up to 15 kg.
- **WARNING:** Never leave you child unsupervised in the stroller!
- **WARNING:** Always use the safety belt when your child is in the stroller.
- The mesh basket is suitable for a maximal weight of 2 kg.
- **ATTENTION:** This stroller is suitable for one baby.
- **WARNING:** The brakes have to be fixed, while taking the child in or out.
- **WARNING:** If you place heavy weight at the handle, the stability of the stroller is in danger.
- **WARNING:** If your carry the stroller up- or downstairs always take your child out of the stroller.
- **WARNING:** When using the carry cot please make sure that the carry cot is fixed in the right way.
- From time please check loosen parts regularly and lock it again.
- **WARNING:** Please make no changes on the stroller, which causes instability.
- Please only use proofed parts manufactured by ABC-Design.
- **WARNING:** Keep away from fire.
- **WARNING:** This stroller is not produced for use while jogging or skating.
- Do not use a Kiddyboard, the stroller is not approved for this.



Articles for baby and child

## Tips

in case of reclamation

- Normal problems regarding to years of wear and damages through heavy uses is no reason for reclamation.
- Damages which are caused by wrong using of this product are no reason for reclamation.
- Damages through wrong installations are no reason for reclamation.
- Damages through wrong using of the stroller are no reason for reclamation.
- Parts of rust caused by missing servicing are no reason for reclamation.
- Scratches are normal damages and are no reasons for reclamation.
- Damp textile parts, which can't be dried or mouldy parts, are no reason for reclamation.
- Through sun intensity, sweat, cleansing agent, rub-downs or often washings, the fabric colour can fade out. And this is also no reason for a reclamation.
- Used wheels are normal damages and are no reason for reclamation.



Articles for baby and child

ABC Design GmbH  
Dr. Rudolf-Eberle-Str. 29  
D-79774 Albbbruck